

# **DREHMO**

**VALVE ACTUATORS**

A member of the AUMA Group

## **Control description for actuators with integrated i-matic control unit type IM**

**V1.06.0086**



Part. no: 383347  
Revision: 2.1  
Date: January 18, 2018

# Table of Contents

<b>1</b>	<b>Structure of the device Menu</b>	<b>4</b>
<b>2</b>	<b>User management</b>	<b>5</b>
<b>3</b>	<b>LEARN mode</b>	<b>6</b>
3.1	Short LEARN mode . . . . .	6
3.2	Change final positions . . . . .	6
3.3	Analogue position value . . . . .	7
3.3.1	Input . . . . .	7
3.3.2	Output . . . . .	7
3.4	Torque calibration . . . . .	8
3.5	Maintenance Encoder . . . . .	9
<b>4</b>	<b>Electronic name plate</b>	<b>10</b>
4.1	Identification . . . . .	10
4.2	Description . . . . .	10
4.3	Actuator . . . . .	10
4.4	Control unit . . . . .	12
4.5	Motor . . . . .	14
4.6	Gear / thrust unit . . . . .	15
4.7	Valve . . . . .	15
<b>5</b>	<b>Oper. data acquisition</b>	<b>17</b>
5.1	General . . . . .	17
5.2	Operation data . . . . .	17
5.3	Dynamic maintenance . . . . .	18
5.4	Faults . . . . .	19
5.5	System data . . . . .	20
<b>6</b>	<b>Actual values/diagnosis</b>	<b>21</b>
6.1	Pending faults . . . . .	21
6.2	Error stack . . . . .	21
6.3	Process data . . . . .	21
6.4	Power supply . . . . .	22
6.5	IO-status . . . . .	22
6.5.1	Outputs . . . . .	22
6.6	System . . . . .	23
6.7	Interface . . . . .	26
6.7.1	Profibus . . . . .	26
6.7.2	Modbus . . . . .	26
6.7.3	Relay interface . . . . .	27
6.8	Battery Backup . . . . .	27

---


---

6.9	Torque curves . . . . .	27
6.9.1	Curve 0 - 3 . . . . .	27
<b>7</b>	<b>Parameters</b>	<b>29</b>
7.1	Power supply . . . . .	29
7.2	Display unit . . . . .	29
7.2.1	Language . . . . .	30
7.2.2	LEDs . . . . .	30
7.3	Data logging . . . . .	32
7.4	Valve . . . . .	33
7.5	Actuator . . . . .	36
7.6	DCS / PLC system . . . . .	37
7.6.1	Emerg. shutdown (ESD) . . . . .	37
7.6.2	Fail safe . . . . .	38
7.6.3	Collective failure 1 - 2 . . . . .	38
7.6.4	Control . . . . .	41
7.6.5	Indications . . . . .	41
7.6.6	Interface . . . . .	42
7.6.6.1	Profibus . . . . .	42
7.6.6.2	Modbus . . . . .	42
7.6.6.3	DeviceNet . . . . .	43
7.6.6.4	Process inputs-Bus . . . . .	43
7.6.6.5	Relay interface . . . . .	43
7.6.6.5.1	Outputs . . . . .	44
7.6.6.5.2	Analogue outputs . . . . .	44
7.6.6.5.3	Command inputs . . . . .	44
7.7	Process . . . . .	45
<b>8</b>	<b>Failures</b>	<b>47</b>
<b>9</b>	<b>Collective failures</b>	<b>53</b>
9.1	Activation of the indications . . . . .	53
<b>10</b>	<b>Digital In- and outputs</b>	<b>55</b>
10.1	Configuration of the outputs . . . . .	55
10.2	Configuration of the process- and command inputs . . . . .	56
<b>11</b>	<b>Anotations for explosion proof actuators</b>	<b>57</b>
11.1	The affected parameters . . . . .	57
11.2	Keeping the actuator explosion proof . . . . .	57
11.2.1	Thermal failure reset. . . . .	57
11.2.2	Thermal overload . . . . .	57
11.2.3	The power unit . . . . .	58

---

# 1 Structure of the device Menu

## Selection menu



### NOTICE

#### **This description contains all parameters**

According to the configuration some parameters may not be displayed in the actuator.

## 2 User management

### User Login

User level: User

Default value: -/-

**Description:**

Selection of the user for login.

### Specialist password

User level: Specialist

Default value: 1234

**Description:**

Setting of the password for the specialist.

### ENTER-TASTE password

User level: User

Default value: 0

**Description:**

Input of the password for the according user.

It consists of 4 digits.

### Actual user

readable from User

Default value: Manufacturer

**Description:**

Output of loggedin user.

### Password from user

User level: Specialist

Default value: Manufacturer

**Description:**

Setting for the use of password. User below the selected one do not need to enter a password.

### User password

User level: User

Default value: 1234

**Description:**

Setting of the password for the user.

### Mainten. staff password

User level: Maintenance staff

Default value: 1234

**Description:**

Setting of the password for maintenance staff.

## 3 LEARN mode

### 3.1 Short LEARN mode

---

#### Closing direction

User level: Maintenance staff

Default value: Clockwise CW

**Description:**

Turning direction of the actuator if the valve is closing.

#### Switching off mode

User level: Maintenance staff

Default value: Final position limit sw.

**Description:**

Sets the switch-off conditions of the valve. During LEARN-mode, this parameter should be set to "Stop position", because the references for the set values are the positions 0% and 100%. Increases in torque due to the kind of valve need to lie outside of this range.

#### Tripping torque CLOSE

User level: Maintenance staff

**Description:**

The actuator switches off if the torque exceeds this value when closing.

#### Tripping torque OPEN

User level: Maintenance staff

**Description:**

The actuator switches off if the torque exceeds this value when opening.

#### Clear position CLOSE

User level: Maintenance staff

Default value: No

**Description:**

Clear position closed. The final position is shifted by 90 turns.

#### Clear position OPEN

User level: Maintenance staff

Default value: No

**Description:**

Clear position open. The final position is shifted by 90 turns.

#### Set position CLOSE

User level: Maintenance staff

Default value:

**Description:**

The actuator can be moved with the buttons „OPEN“ and „CLOSE“ as if in LOCAL mode. „ENTER“ sets the final position to the current position, „EC“ cancels the procedure without setting the final position.

#### Set position OPEN

User level: Maintenance staff

Default value:

**Description:**

The actuator can be moved with the buttons „OPEN“ and „CLOSE“ as if in LOCAL mode. „ENTER“ sets the final position to the current position, „EC“ cancels the procedure without setting the final position.

### 3.2 Change final positions

---

#### Clear position CLOSE

User level: Maintenance staff

Default value: No

**Description:**

Clear position closed. The final position is shifted by 90 turns.

### 3. LEARN MODE

---

#### Clear position OPEN

User level: Maintenance staff

Default value: No

**Description:**

Clear position open. The final position is shifted by 90 turns.

#### Set position CLOSE

User level: Maintenance staff

Default value:

**Description:**

The actuator can be moved with the buttons „OPEN“ and „CLOSE“ as if in LOCAL mode. „ENTER“ sets the final position to the current position, „EC“ cancels the procedure without setting the final position.

#### Set position OPEN

User level: Maintenance staff

Default value:

**Description:**

The actuator can be moved with the buttons „OPEN“ and „CLOSE“ as if in LOCAL mode. „ENTER“ sets the final position to the current position, „EC“ cancels the procedure without setting the final position.

#### Set CLOSE position

User level: Maintenance staff

Default value: -/-

**Description:**

Defines the actual setpoint current as the setpoint value for position closed. If this parameter is used, the parameter "Value CLOSE" is automatically set.

#### Value OPEN

User level: Maintenance staff

Default value: 964

**Description:**

Adjusts the numerical value of the A/D converter of the setpoint signal to the position OPEN.

#### Value CLOSE

User level: Maintenance staff

Default value: 29

**Description:**

Adjusts the numerical value of the A/D converter of the setpoint signal to the position CLOSE.

## 3.3 Analogue position value

### 3.3.1 Input

---

#### Set OPEN position

User level: Maintenance staff

Default value: -/-

**Description:**

Defines the actual setpoint current as the setpoint value for position open. If this parameter is used, the parameter "Value OPEN" is automatically set.

### 3.3.2 Output

---

#### Value 100%

User level: Maintenance staff

Default value: 849

**Description:**

Sets the value for the D/A converter which corresponds to the position of 100%.

#### Value 0%

User level: Maintenance staff

Default value: 62

**Description:**

Sets the value for the D/A converter which corresponds to the position of 0%.

## 3.4 Torque calibration

### Delete torque OPEN

User level: Specialist

Default value: No

**Description:**

Deletes all calibration data of the torque sensor for opening direction. Afterwards the calibration has to be executed by using torque OPEN 50% and 100%.

### Delete torque CLOSE

User level: Specialist

Default value: No

**Description:**

Deletes all calibration data of the torque sensor for closing direction. Afterwards the calibration has to be executed by using torque CLOSE 50% and 100%.

### Zero point adjust

User level: Maintenance staff

Default value: No

**Description:**

Defines the actual torque as 0 Nm.

### torque OPEN 50%

User level: Specialist

**Description:**

Sets the calibration value for the torque in opening direction with a level of 50%. The actuator opens the valve upon pushing "OPEN" and moves until the button is pressed again to set the value of 50% in opening direction. The actuator then stops automatically.

To function properly, the closing direction has to be set to „CW“!

### torque OPEN 100%

User level: Specialist

**Description:**

Sets the calibration value for the torque in opening direction with a level of 100%. The actuator opens the valve upon pushing "OPEN" and moves until the button is pressed again to set the value of 100% in opening direction. The actuator then stops automatically.

To function properly, the closing direction has to be set to „CW“!

### torque CLOSE 50%

User level: Specialist

**Description:**

Sets the calibration value for the torque in closing direction with a level of 50%. The actuator closes the valve upon pushing "CLOSE" and moves until the button is pressed again to set the value of 50% in closing direction. The actuator then stops automatically.

To function properly, the closing direction has to be set to „CW“!

### torque CLOSE 100%

User level: Specialist

**Description:**

Sets the calibration value for the torque in closing direction with a level of 100%. The actuator closes the valve upon pushing "CLOSE" and moves until the button is pressed again to set the value of 100% in closing direction. The actuator then stops automatically.

To function properly, the closing direction has to be set to „CW“!

### Torque centered

readable from User

**Description:**

Displays the current value of the excursion of the torque axle. With "ENTER-TASTE" this value can be displayed in big letters.

## 3.5 Maintenance Encoder

### Upload calibration

User level: Maintenance staff

Default value: No

**Description:**

Transfer of the sensor calibration data into the control unit.

### Download calibration

User level: Maintenance staff

Default value: No

**Description:**

Transfer of the sensor calibration data from the control unit into the sensor.

### Default calibration

User level: Maintenance staff

Default value: No

**Description:**

Transfer preset calibration data to the sensor according to the corresponding actuator types.

NOTICE: The torque values may not be exact due to mechanical tolerances.

### Calibr. gradient CLOSE

User level: Manufacturer

Default value: 0

**Description:**

The slope is calculated, based on the two taught points for the torque in direction CLOSE, by the equation:  $y=mx+b$ .

### Calibr. gradient OPEN

User level: Manufacturer

Default value: 0

**Description:**

The slope is calculated, based on the two taught points for the torque in direction OPEN, by the equation:  $y=mx+b$ .

### Calibr. offset CLOSE

User level: Manufacturer

Default value: 0

**Description:**

The offset is calculated, based on the two taught points for the torque in direction CLOSE, by the equation:  $y=mx+b$ .

### Calibr. offset OPEN

User level: Manufacturer

Default value: 0

**Description:**

The offset is calculated, based on the two taught points for the torque in direction CLOSE, by the equation:  $y=mx+b$ .

## 4 Electronic name plate

### 4.1 Identification

---

**Bluetooth name**

readable from User

Default value:

**Description:**

Shows the actual name tag of the actuator that will be displayed during a bluetooth discovery.

**Bluetooth address**

readable from User

Default value: 0

**Description:**

Shows the bluetooth MAC address of the actuator that will be displayed during a bluetooth discovery.

### 4.2 Description

---

**TAG/KKS-ID**

User level: Maintenance staff

Default value: `__TAG_KKS__`

**Description:**

Process-specific identification of the actuator

**Application**

User level: Maintenance staff

Default value: `__APPLICATION__`

**Description:**

Description of the actuator

**Installation area**

User level: Maintenance staff

Default value: `__INSTAREA__`

**Description:**

Process-specific part, where the actuator is installed

**Assembly date**

User level: Maintenance staff

Default value: `__MOUNTDATE__`

**Description:**

date when actuator was installed

**Commission no.**

User level: Specialist

Default value: `__KOMNR__`

**Description:**

Commission-number of the manufacturer

### 4.3 Actuator

---

**Manufacturer**

User level: Specialist

Default value: Drehmo GmbH

**Description:**

Indication about the actuators manufacturer

**Actuator identifier no.**

User level: Specialist

Default value: `__DRIVEIDENT__`

**Description:**

Description of the actuator according to key with output and speed (e.g. DiM30 A-25)

**Actuator model**

User level: Specialist

Default value: electrical

**Description:**

Power source of the actuator

### Serial number

readable from User  
Default value: -/-

**Description:**

Actuator serial number => setting defined by device key

### Device certifications

User level: Specialist  
Default value: NA

**Description:**

Device certifications

### Mech. output form

User level: Specialist  
Default value: \_\_DROUTPUT\_\_

**Description:**

Mechanical output form

### Rpm

User level: Specialist  
Default value: 0

**Description:**

Speed of the output / Rpm

### Time / 90°

User level: Specialist  
Default value: 0

**Description:**

The time needed to turn 90° (for DPiM)

### Protection class

User level: Specialist  
Default value: IP67

**Description:**

Protection class

### Type of duty

User level: Specialist  
Default value: S4/35%ED

**Description:**

Operational mode of the actuator (e.g. S2 10 min.)

### max. tripping torque

readable from User  
Default value: 0

**Description:**

Maximum available torque of the actuator output => setting defined by device key (see Control unit)

### min. tripping torque

readable from User  
Default value: 0

**Description:**

Minimum available torque of the actuator output.

Lower torques than this value cannot be detected! => setting defined by device key

### max. modulating torque

readable from User  
Default value: 0

**Description:**

Maximum available torque for modulating mode => setting defined by device key

### min. ambient temp.

User level: Specialist  
Default value: -25

**Description:**

Minimum allowed temperature when electronic unit is powered (heating is on)

### max. ambient temp.

User level: Specialist  
Default value: 60

**Description:**

Maximum allowed temperature

## 4.4 Control unit

---

### Device Key

User level: User

Default value: 0000-0000-0000-0000

#### *Description:*

This key defines the configuration of the control unit (e.g. integral positioner, timer). A new key is only valid after a reset procedure.

### Device Manufacturer ID

readable from User

Default value: 305

#### *Description:*

Manufacturer ID assigned by the PNO.

### Device Id

readable from User

Default value: i-Matic DiM

#### *Description:*

Kind of electronic

### Serial number

readable from User

Default value: -/-

#### *Description:*

Serial number of electronic unit

### Snr. base plate

readable from User

Default value: -/-

#### *Description:*

Serial number of base plate

### Snr. display plate

readable from User

Default value: -/-

#### *Description:*

Serial number of display plate

### Snr. Interface 1

readable from User

Default value: -/-

#### *Description:*

Serial number of Interface board

### Snr. Interface 2

readable from User

Default value: -/-

#### *Description:*

Serial number of additional, optional interface board

### Serial number EM6

readable from User

Default value: -/-

#### *Description:*

Serial number of combined sensor Em6

### Snr. EM6 Remote

readable from User

Default value: -/-

#### *Description:*

Serial number of board inside actuator for wall mounted unit

### Wiring diagram

User level: Specialist

Default value: iM00X-XX-X X-X X X/X

#### *Description:*

Wiring diagram of the actuator

### Electrical specification

User level: Specialist

Default value: iM00X-XX-X X-X X X/X

#### *Description:*

Lists the electronic components of the actuator

### SW-Revision baseplate

readable from User

Default value: -/-

**Description:**

Software version of main board

### HW-Revision baseplate

readable from User

Default value: -/-

**Description:**

Hardware version of main board

### SW-Revision display

readable from User

Default value: -/-

**Description:**

Software version of display board

### HW-Revision Display

readable from User

Default value: -/-

**Description:**

Hardware version of display board

### HW-Revision Interface 1

readable from User

Default value: -/-

**Description:**

Hardware version of interface board

### HW-Revision Interface 2

readable from User

Default value: -/-

**Description:**

Hardware version of additional, optional interface board

### Internal positioner

readable from User

Default value: Disabled V003

**Description:**

Information, whether the internal positioner is enabled or not => setting defined by device key

### Local remote control

readable from User

Default value: Disabled

**Description:**

Information, whether the actuator can be remote controlled using the interface of the display unit => setting defined by device key

### Enhanced controller

readable from User

Default value: Disabled

**Description:**

This parameter controls the use of the enhanced controller that provides more complex settings for the controller.

### max. electr. temp.

User level: Specialist

Default value: 85

**Description:**

The maximum allowed temperature of electronic

### min. electronics temp.

User level: Specialist

Default value: -25

**Description:**

The minimum allowed temperature of electronic

## 4.5 Motor

---

### Motor type

User level: Specialist

Default value: `_MOTORTYPE_`

**Description:**

Type of the motor

### Motor serial no.

User level: Specialist

Default value: 123456

**Description:**

Serial number of the motor

### Insulation class

User level: Specialist

Default value: F

**Description:**

Insulation class of the motor

### Nominal voltage

User level: Specialist

Default value: 400

**Description:**

Nominal voltage

### Phases

User level: Specialist

Default value: 3

**Description:**

Number of phases of the main power system

### Nominal frequency

User level: Specialist

Default value: 50

**Description:**

Frequency of the main power system

### Nominal current

User level: Specialist

Default value: 0.75

**Description:**

Nominal current

### Starting current

User level: Specialist

Default value: 1.1

**Description:**

Maximum current when motor is energised

### Nominal power

User level: Specialist

Default value: 1.1

**Description:**

Nominal power

### Phase shift (cos phi)

User level: Specialist

Default value: 0.65

**Description:**

Value of  $\cos(\varphi)$  at nominal values

### Motor protection

User level: Specialist

Default value: PTC

**Description:**

Sensor of motor temperature

### Output speed / Rpm

User level: Specialist

Default value: 1360

**Description:**

Speed of motor at nominal values

## 4.6 Gear / thrust unit

---

### Manufacturer

User level: Maintenance staff  
Default value: `_GEARMANUF_`

**Description:**

Manufacturer

### Add. gear model

User level: Maintenance staff  
Default value: `_GEARTYPE_`

**Description:**

type of additional component

### Serial number

User level: Maintenance staff  
Default value: `_GEARSERNR_`

**Description:**

Serial number of component

### Gearbox assembly date

User level: Maintenance staff  
Default value: `_GEARMOUNTDATE_`

**Description:**

Date of installation of component

### max. input torque

User level: Maintenance staff  
Default value: 0

**Description:**

Value of maximum permissible input torque of component.

The parameter "Tripping torque CLOSE", "Tripping torque OPEN" in the submenu valve cannot exceed this value.

### Gear ratio

User level: Maintenance staff  
Default value: 1

**Description:**

Gear ratio

### Gear factor

User level: Maintenance staff  
Default value: 1

**Description:**

Gear factor

### Mech. output form

User level: Maintenance staff  
Default value: `_GEAROUTPUT_`

**Description:**

Mechanical form of output

## 4.7 Valve

---

### Manufacturer

User level: Maintenance staff  
Default value: `_VALVEMANUF_`

**Description:**

Manufacturer of the valve, which was delivered with the actuator

### Valve type

User level: Maintenance staff  
Default value: linear

**Description:**

Information about the moving of the valve

### Adjustment range

User level: Maintenance staff  
Default value: 90

**Description:**

Information about the stroke in the configured unit (see parameters>data logging>position unit)

### Serial number

User level: Maintenance staff  
Default value: `_VALVESERNR_`

**Description:**

Serial number of valve

**max. torque OPEN**

User level: Maintenance staff

Default value: 0

***Description:***

Maximum permissible torque of valve or gear in direction open. A value of 0 means no restriction.

**max. torque CLOSE**

User level: Maintenance staff

Default value: 0

***Description:***

Maximum permissible torque of valve or gear in direction close. A value of 0 means no restriction.

## 5 Oper. data acquisition

### 5.1 General

---

#### Calibration date

User level: Specialist

Default value: 2003-08-08

**Description:**

Date, when actuator was last calibrated.

#### Configuration date

User level: Maintenance staff

Default value: 2002-08-08

**Description:**

This field can be used to store the date of the last configuration changes

#### Maintenance date

User level: Maintenance staff

Default value: 2002-08-08

**Description:**

This field can be used to store the date of the last maintenance

#### Motor oper. time total

readable from User

Default value: 0

**Description:**

Operating time of motor – this value cannot be reset

#### Motor operation time

User level: Specialist

Default value: 0

**Description:**

Accumulated operating time of motor

#### Position trippings total

readable from User

Default value: 0

**Description:**

Number of stops due to reaching a final position – this value cannot be reset.

### 5.2 Operation data

---

#### Valve stroke

User level: Specialist

Default value: 0

**Description:**

Value of the accumulated valve travel in multiples of complete stroke (= 1)

#### > Limit valve stroke

User level: Maintenance staff

Default value: 0

**Description:**

Maximum allowed valve travel in multiples of complete stroke (= 1).

If the value is exceeded, an indication "maintenance required" is generated. If value "0" is set, this check is disabled.

#### Position trippings

User level: Specialist

Default value: 0

**Description:**

Number of stops due to reaching a final position

#### Operation cycles

User level: Specialist

Default value: 0

**Description:**

Number of motor startups

**> Limit cycles**

User level: Maintenance staff

Default value: 0

**Description:**

Limit of number of motor startups. If the value is exceeded, an indication "maintenance essential" is generated. If value is set to "0", this check is disabled.

**Actual op. cycles/h**

readable from User

Default value: 0

**Description:**

Information of number of motor startups during the last hour.

Value is updated continuously

**max. cycles / hour**

User level: Specialist

Default value: 0

**Description:**

Record of maximum value of "Actual op. cycles / h".

**> Limit cycles / hour**

User level: Maintenance staff

Default value: 0

**Description:**

Limit of number of motor startups during one hour.

If the value is exceeded, an indication "maintenance required" is output.

**Operation time CLOSE**

readable from User

Default value: 0

**Description:**

Duration of the last complete closing of the valve starting at open position

**Operation time OPEN**

readable from User

Default value: 0

**Description:**

Duration of last complete opening of the valve starting at close position

**Actual operation time**

readable from User

Default value: 0

**Description:**

Duration of last movement

**Actual duty cycle value**

readable from User

Default value: 0

**Description:**

Duration of energised motor during the last hour.

Value is updated continuously.

**max. duty cycle value**

User level: Specialist

Default value: 0

**Description:**

Information about longest duration of energised motor during one hour.

## 5.3 Dynamic maintenance

---

**Thermal ageing**

User level: Specialist

Default value: 0

**Description:**

Calculates the ageing process of temperature dependent components of the actuator like gaskets. Those ageing processes are depending on the ambient temperature.

### > Limit thermal ageing

User level: Maintenance staff

Default value: 87600

**Description:**

Limit for the thermal ageing. If this value is exceeded, the indications "maintenance essential" and "Gasket change recomm." are generated. If value is set to "0", this check is disabled.

### Temperature corr. value

User level: Maintenance staff

Default value: -10

**Description:**

Defines the difference between measured and ambient temperature. E.g. if set to 10°C, the ambient temperature is 10K less than the measured temperature.

### Mechanical ageing

User level: Specialist

Default value: 0

**Description:**

Calculates the abrasion of components of the internal gear.

### Type mech. ageing

User level: Maintenance staff

Default value: No

**Description:**

This parameter defines the algorithm used for the calculation of the mechanical ageing.

It is required to select the adequate actuator type in order to use the correct calculation algorithm.

Setting of the value to "No" results in a deactivation of the mechanical ageing calculation.

### > Limit mechanical ageing

User level: Maintenance staff

Default value: 0

**Description:**

Limit for mechanical ageing. If this value is exceeded, the indications "maintenance essential" and "gear overhaul recomm." are generated. If value is set to "0", this check is disabled.

### > Preset mechanical ageing

User level: Maintenance staff

Default value: No

**Description:**

This parameter can be used to preset the "> Limit mechanical ageing" to a limit fitting to the present actuator size.

## 5.4 Faults

### Torque tripping

User level: Specialist

Default value: 0

**Description:**

Number of stops due to a torque exceeding the "Tripping torque ..."

### Torque warnings

User level: Specialist

Default value: 0

**Description:**

Number of warnings due to a torque exceeding the "Torque warning level"

### Thermal overload

readable from User

Default value: 0

**Description:**

Number of times when motor was overheated

**Actuator start failures**

readable from User

Default value: 0

**Description:**

This parameter can be used to preset the "> Limit mechanical ageing" to a limit fitting to the present actuator size.

## 5.5 System data

---

**Up time electronic**

readable from User

Default value: 0

**Description:**

The time the electronic was energised

**Number of power on**

readable from User

Default value: 0

**Description:**

The number of system resets

**Electronics overtemp.**

readable from User

Default value: 0

**Description:**

Accumulated duration of electronic temperature exceeding maximum allowed value.

## 6 Actual values/diagnosis

### Simulate alarm

User level: Specialist  
 Default value: 0

**Description:**

Simulates alarms for test purposes.

### Actual position

readable from User  
 Default value: 0

**Description:**

Displays the position in the unit specified in parameters>data logging>position unit

### 6.1 Pending faults

readable from User  
 Default value:

**Description:**

This parameter contains a list of faults that are indicated as soon as they occur.

### Setpoint position

readable from User  
 Default value: 0

**Description:**

Displays the setpoint value in the unit specified

### 6.2 Error stack

---

#### Fault t-0 - 9

readable from User  
 Default value: None

**Description:**

Shows the kind of last error and when it occurred

#### Time t-0 - 9

readable from User  
 Default value: 0

**Description:**

Shows the time (Up time electronic) of the fault

### Torque

readable from User  
 Default value: 0

**Description:**

Displays the current torque

### Fail safe

readable from User  
 Default value: Disabled

**Description:**

Information about the state of the fail safe function

### Emerg. shutdown (ESD)

readable from User  
 Default value: Enabled

**Description:**

Information about the state of the emergency shutdown command.

### 6.3 Process data

---

#### Operation mode

readable from User  
 Default value: OFF

**Description:**

Displays the active mode

Enabled:  
 External emergency shutdown is requested.

Disabled:  
 External emergency shutdown is not requested.

## 6.4 Power supply

---

### Phase sequence

readable from User  
Default value: Failure

**Description:**

Information about the input power

### Phase 1

readable from User  
Default value: Failure

**Description:**

Displays the state of phase L1.  
The indication is reset with the next movement or with a fault acknowledgement.

### Phase 2

readable from User  
Default value: Failure

**Description:**

Displays the state of phase L2.  
The indication is reset with the next movement or with a fault acknowledgement.

### Phase 3

readable from User  
Default value: Failure

**Description:**

Displays the state of phase L3.  
The indication is reset with the next movement or with a fault acknowledgement.

### 24V internal

readable from User  
Default value: Failure

**Description:**

Displays the state of the 24 V driven by the main power

### 24V external

readable from User  
Default value: Failure

**Description:**

Displays the state of the externally powered 24 V

## 6.5 IO-status

---

### Command Inputs

Default value:

**Description:**

Information about the command inputs (activated / deactivated).

### Analogue outputs

Default value:

**Description:**

Information about the analogue outputs (activated / deactivated).

### 6.5.1 Outputs

---

#### Final position reached

readable from User  
Default value: No

**Description:**

Limit position OPEN or CLOSED reached

#### Final position OPEN

readable from User  
Default value: No

**Description:**

Limit position OPEN reached

### Final position CLOSE

readable from User

Default value: No

**Description:**

Indicates that the actuator is in the final position CLOSE. According the parameter setting of "Final position indication", the actuator position is higher than the setting of end position CLOSE or the output torque exceeds the "Tripping torque close". Depends on "Switching off mode" setting for the valve too.

### Intermediate position 1 - 2

readable from User

Default value: No

**Description:**

Indicates that the actuator position is in the range between the final position CLOSE and the parameterized "Intermediate position 1".

### Actuator running

readable from User

Default value: No

**Description:**

Indicates that the final power control unit of the actuator is switched on.

### Actuator closing

readable from User

Default value: No

**Description:**

Indicates that the final power control unit of the actuator is switched on in order to run into direction CLOSE.

### Actuator opening

readable from User

Default value: No

**Description:**

Indicates that the final power control unit of the actuator is switched on in order to run into direction OPEN.

### Command Inputs

Default value:

**Description:**

Information about the command inputs (activated / deactivated).

### Analogue outputs

Default value:

**Description:**

Information about the analogue outputs (activated / deactivated).

## 6.6 System

### Electronic temperature

readable from User

Default value: 0

**Description:**

Displays the temperature of electronic

### LED Test

User level: User

Default value: Test LEDs

**Description:**

The three Local Lamps can be checked for functionality by using the buttons "Feld nach oben", "ESC-TASTE", and "Feld nach unten".

With "enter" the test is aborted.

### NV-Memory failure

readable from User

Default value: No

**Description:**

Displays whether the non-volatile memory showed an error during the boot procedure

**EM6 setup failure**

readable from User

Default value: No

**Description:**

Information, whether the final positions are correctly set (e.g. closing direction of valve is set to CCW, limit positions are still for direction of closing the valve CW => value is "Yes")

**EM6 Error code**

readable from User

Default value: 0

**Description:**

The control unit checks the combined sensor (EM6) during the automatically performed self test.

In case of an error the indication "Combisensor failure" is activated. This parameter describes which kind of error was detected. The EM6 is checked in several steps which generate different error code groups.

Errors during general communication with EM6:

101 - no communication possible with remote EM6

102 - no communication possible with remote EM6

103 - no communication possible with remote EM6

104 - no communication possible with remote EM6

105 - no communication possible with remote EM6

106 - reference voltage is not valid

107 - communication to remote EM6 is lost

108 - reference voltage is no longer valid

109 - critical communication error with EM6

The non-volatile memory of the combined sensor EM6 is checked in regular intervals. Detected errors are coded as follows:

- 1 - Read error of serial number
- 2 - Read error of offset of angle
- 3 - Read error of correction factor for analogue values
- 4 - Read error of closing direction
- 5 - Read error of torque value
- 6 - Read error of LEARN values
- 7 - Read error of checksum flag

Errors with wall mounted unit:

- 11 - Read error of serial number
- 12 - Read error of serial number of board DiM-06
- 13 - Read error of part number of board DiM-06
- 14 - Read error of closing direction
- 15 - Read error of torque value
- 16 - Read error of LEARN values

**HW interface failure**

readable from User

Default value: No

**Description:**

Information, whether the communication to the interface board is OK

### System test Error code

readable from User

Default value: 0

**Description:**

Displays the code of the error which occurred during the self test of the actuator. Depending on the kind of error the system generates a reset and after power up assumes the state failsafe or just activates this indication.

- 0 - (0x00) - no error detected
- 1 - (0x01) - error during master routine
- 2 - (0x02) - watchdog (hardware) was elapsed
- 3 - (0x03) - watchdog (software) was elapsed
- 8 - (0x08) - stack overflow
- 9 - (0x09) - stack underflow
- 10 - (0x0A) - unrecoverable hardware error - the electronic performs a reset until error is no longer valid!
- 17 - (0x11) - error during testing the flash memory
- 18 - (0x12) - error while reading the starting pattern of the flash memory
- 19 - (0x13) - error while reading the ending pattern of the flash memory
- 20 - (0x14) - error during checksum test of flash memory

### System test history

readable from User

Default value: 00

**Description:**

Displays the code of the last error which occurred during the self test of the actuator (stored).

Depending on the kind of error the system generates a reset and after power up assumes the state failsafe or just activates this indication.

- 0 - (0x00) - no error detected
- 1 - (0x01) - error during master routine
- 2 - (0x02) - watchdog (hardware) was elapsed
- 3 - (0x03) - watchdog (software) was elapsed
- 8 - (0x08) - stack overflow
- 9 - (0x09) - stack underflow
- 10 - (0x0A) - unrecoverable hardware error - the electronic performs a reset until error is no longer valid!
- 17 - (0x11) - error during testing the flash memory
- 18 - (0x12) - error while reading the starting pattern of the flash memory
- 19 - (0x13) - error while reading the ending pattern of the flash memory
- 20 - (0x14) - error during checksum test of flash memory

### System test duration

readable from User

Default value: 0

**Description:**

Displays the last duration for the self-test of the electronic unit in milliseconds

### Discrepancy Error code

readable from User

Default value: 0

**Description:**

Displays the error code describing the fault detected during discrepancy analysis of the power driver. If an error was detected the actuator can't be operated any more.

- 0 - (0x00) - no error detected
- 1 - (0x01) - error in circuit+24V POW OFF
- 2 - (0x02) - error in circuit+24V POW ON
- 3 - (0x03) - error in circuit+24V ELR\_POW\_FB OFF
- 4 - (0x04) - error in circuit+24V POW OFF
- 5 - (0x05) - error in circuit SAUF
- 6 - (0x06) - error in circuit SZU
- 7 - (0x07) - error in circuit +24V POW OFF
- 8 - (0x08) - error in circuit ELRAUF
- 9 - (0x09) - error in circuit ELRZU
- 10 - (0x0A) - Ausgang POW\_EN not set, FeedbackPOW\_RB active
- 11 - (0x0B) - Ausgang POW\_EN set, Feedback POW\_RB inactive
- 12 - (0x0C) - ELR\_ZU and ELR\_AUF not set, Feedback ELR\_RB active
- 13 - (0x0D) - ELR\_ZU or ELR\_AUF set, FeedbackELR\_RB inactive

## 6.7 Interface

### Interface type

readable from User

Default value: Relays

**Description:**

Information about the kind of interface card

### Baudrate

readable from User

**Description:**

The actual transmission speed of the fieldbus interface is given

### Binary inputs

readable from User

**Description:**

Displays the data of the telegram to the fieldbus master in hexadecimal numbers ⇒ refer to complementary operating manual for actuators with fieldbus systems.

### Binary outputs

readable from User

**Description:**

Displays the data of the telegram from the fieldbus master in sedecimal numbers ⇒ refer to complementary operating manual for actuators with fieldbus systems.

### 6.7.1 Profibus

#### Bus profile

readable from User

Default value: DPV1

**Description:**

Defines, which services of the PROFIBUS system are available => setting defined by device key

#### Param. Error code

readable from User

Default value: 0

**Description:**

Coded notification of errors concerning the configuration of the parameters for Profibus.

### 6.7.2 Modbus

#### Bus profile

readable from User

Default value: Redundant

**Description:**

Defines, whether the actuator is equipped with one or two transmission channels => setting defined by device key

### 6.7.3 Relay interface

#### Extension relay

readable from User

Default value: 4 latching relays

**Description:**

Information, which kinds of additional relays are mounted onto the relay board

#### Interface type

readable from User

Default value: Relays

**Description:**

Information about the kind of interface card

#### Baudrate

readable from User

**Description:**

The actual transmission speed of the fieldbus interface is given

#### Binary inputs

readable from User

**Description:**

Displays the data of the telegram to the fieldbus master in hexadecimal numbers ⇒ refer to complementary operating manual for actuators with fieldbus systems.

#### Binary outputs

readable from User

**Description:**

Displays the data of the telegram from the fieldbus master in sedecimal numbers ⇒ refer to complementary operating manual for actuators with fieldbus systems.

## 6.8 Battery Backup

#### State

readable from User

Default value: -/-

**Description:**

Display the state of the internal accumulator. The battery backup must be enabled by software to function properly.

#### Temperature

readable from User

Default value: -/-

**Description:**

Information about the temperature of the internal accumulator

Charge-/discharge range = 0...45°C of electronic unit

Discharge range = -30°C...60°C of electronic unit

Excess/insuff. Temp. = out of discharge range

## 6.9 Torque curves

### 6.9.1 Curve 0 - 3

#### Curve 0 -> Curve 0 - 3

User level: Maintenance staff

Default value: -/-

**Description:**

Stores the last recorded torque curve as curve 0.

#### Show

User level: Maintenance staff

Default value:

**Description:**

Shows the coresponding torque curve on the display.

**Description curve 0 - 3**

User level: Maintenance staff

Default value: Default 0

**Description:**

Describing text for curve x.

**T CLOSE\_OPEN - 0 - 3**

readable from User

Default value:

**Description:**

Time stamp of curve x for opening.

**T OPEN\_CLOSE - 0 - 3**

readable from User

Default value:

**Description:**

Time stamp of curve x for closing.

**Simulate alarm**

User level: Specialist

Default value: 0

**Description:**

Simulates alarms for test purposes.

# 7 Parameters

## Load factory settings

User level: Maintenance staff

Default value: No

**Description:**

The factory setting will be loaded

## Store factory settings

User level: Specialist

Default value: No

**Description:**

Stores the settings as factory setting.

## 7.1 Power supply

### Phase correction

User level: Maintenance staff

Default value: Enabled

**Description:**

Defines the rotating field for the connected power system. If set to "Detect", the rotating field is checked continuously.

### Phase monitoring

User level: Maintenance staff

Default value: Enabled latching

**Description:**

If activated detects if a phase is missing. In this case the motor is de-energised, and the indication "phase failure" is given. The indication is reset with the next movement or fault acknowledgement.

### Phase monitoring delay

User level: Maintenance staff

Default value: 1

**Description:**

Defines the delay time of the indications "phase correction error" or "Failure of internal 24V".

## 7.2 Display unit

### Maintain mode LOCAL

User level: Maintenance staff

Default value: Disabled

**Description:**

If this parameter is enabled and a local command close or open is given, the actuator runs until a final position is reached or an error occurs.

### Orientation

User level: Maintenance staff

Default value: Normal

**Description:**

Specifies if the display content is shown normal or 180° rotated.

### Lock display unit

User level: Maintenance staff

Default value: Ignore signal

**Description:**

Defines how the command "Enable LOCAL" works:

- "Disable completely" is like having a lock through the enter button - no push button can be operated
- "Disable local operation" only disables the motor operation
- "Ignore signal" disables this command input

### PC-interface

User level: Maintenance staff

Default value: Enabled

**Description:**

This parameter can block the Infrared- or bluetooth-port.

**Position output**

User level: Maintenance staff  
Default value: Over-/underflow

**Description:**

Defines how the position is displayed:  
- With "Over-/underflow" the position is not limited to values between CLOSE and OPEN  
(see data logging -> high scale value, low scale value)  
- With "Limited" the displayed position is limited to the range between CLOSE and OPEN

**Bluetooth PIN**

User level: Maintenance staff  
Default value: 0

**Description:**

This parameter defines the PIN of the optional available Bluetooth interface.  
The PIN is used for authentication of the actuator during connexion establishment with the master station.

**Bluetooth name**

User level: Maintenance staff  
Default value: Serial number

**Description:**

Defines the distinct identification of the actuator regarding the Bluetooth interface.

**LCD backlight delay**

User level: User  
Default value: 30

**Description:**

Sets the time after which the backlight is switched off if no button is pressed

**Automatic logout**

User level: Maintenance staff  
Default value: Disabled

**Description:**

Defines whether and how an automatic logout is accomplished

**Logout delay time**

User level: Maintenance staff  
Default value: 10

**Description:**

Sets the time after which an automatic logout is accomplished

---

**7.2.1 Language****Language**

User level: User  
Default value: German

**Description:**

Sets the language of the display

**Loaded language**

User level: User  
Default value: German

**Description:**

Sets the language of the display

---

**7.2.2 LEDs****Running indication**

User level: Maintenance staff  
Default value: directional flashing

**Description:**

This parameter sets the indication behavior of the LOCAL LAMPS during energized motor.

**Position indication**

User level: Maintenance staff  
Default value: Final positions

**Description:**

This parameter sets the indication behavior of the LOCAL LAMPS in the end positions and intermediate positions.

## 7. PARAMETERS

---

### **Colour LED OPEN**

User level: Maintenance staff

Default value: Green

**Description:**

Selection of the colour for the LED that indicates the waypoint OPEN. There are 8 choosable colours : blue, green, red, orange, cyan, pink, white.

### **Colour LED Torque OPEN**

User level: Maintenance staff

Default value: Orange

**Description:**

Selection of the colour for the LED that indicates the torque in direction OPEN. There are 8 choosable colours (see parameter Colour LED OPEN).

### **Colour LED Fault**

User level: Maintenance staff

Default value: Red

**Description:**

Selection of the colour for the LED that indicates a fault. There are 8 choosable colours (see parameter Colour LED OPEN).

### **Colour LED Torque CLOSE**

User level: Maintenance staff

Default value: Orange

**Description:**

Selection of the colour for the LED that indicates the torque in direction CLOSE. There are 8 choosable colours (see parameter Colour LED OPEN).

### **Colour LED CLOSE**

User level: Maintenance staff

Default value: Yellow

**Description:**

Selection of the colour for the LED that indicates the waypoint CLOSE. There are 8 choosable colours : blue, green, red, orange, cyan, pink, white.

### **Maintain mode LOCAL**

User level: Maintenance staff

Default value: Disabled

**Description:**

If this parameter is enabled and a local command close or open is given, the actuator runs until a final position is reached or an error occurs.

### **Orientation**

User level: Maintenance staff

Default value: Normal

**Description:**

Specifies if the display content is shown normal or 180° rotated.

### **Lock display unit**

User level: Maintenance staff

Default value: Ignore signal

**Description:**

Defines how the command "Enable LOCAL" works:

- "Disable completely" is like having a lock through the enter button - no push button can be operated
- "Disable local operation" only disables the motor operation
- "Ignore signal" disables this command input

### **PC-interface**

User level: Maintenance staff

Default value: Enabled

**Description:**

This parameter can block the Infrared- or bluetooth-port.

**Position output**

User level: Maintenance staff  
Default value: Over-/underflow

**Description:**

Defines how the position is displayed:  
- With "Over-/underflow" the position is not limited to values between CLOSE and OPEN  
(see data logging -> high scale value, low scale value)  
- With "Limited" the displayed position is limited to the range between CLOSE and OPEN

**Bluetooth PIN**

User level: Maintenance staff  
Default value: 0

**Description:**

This parameter defines the PIN of the optional available Bluetooth interface.  
The PIN is used for authentication of the actuator during connexion establishment with the master station.

**Bluetooth name**

User level: Maintenance staff  
Default value: Serial number

**Description:**

Defines the distinct identification of the actuator regarding the Bluetooth interface.

**LCD backlight delay**

User level: User  
Default value: 30

**Description:**

Sets the time after which the backlight is switched off if no button is pressed

**Automatic logout**

User level: Maintenance staff  
Default value: Disabled

**Description:**

Defines whether and how an automatic logout is accomplished

**Logout delay time**

User level: Maintenance staff  
Default value: 10

**Description:**

Sets the time after which an automatic logout is accomplished

---

## 7.3 Data logging

**Torque unit**

User level: Maintenance staff  
Default value: Nm

**Description:**

Sets the unit for the torque

**Torque unit old**

Default value: Nm

**Description:**

Compares the old unit with the new one. If a change is detected a conversion into the new unit will be triggered.

**Torque sign**

User level: Maintenance staff  
Default value: Absolute value

**Description:**

Defines if the torque should be shown as 0..100% or as -100...+100%

## 7. PARAMETERS

---

### Output Torque

User level: Maintenance staff

Default value: Actual value

**Description:**

Defines the output of the torque value. With "Actual value" the current torque is output.

When using slow fieldbus or DCS systems, peaks of the torque might not be detected. "Max. value" outputs the maximum torque of the last movement. A new movement re-sets the value of the torque.

"Max. value wo. fin. Pos." (Maximum value without final positions) is identical to "Max. value",

except that the value of the torque is not output within the range of the final positions.

With "Trend value" the maximum value of the torque is output for 1 second, and automatically cleared afterwards.

We recommend this function for slow DCS systems.

### High scale value

User level: Maintenance staff

Default value: 100

**Description:**

Defines which value corresponds to the final position OPEN

### Low scale value

User level: Maintenance staff

Default value: 0

**Description:**

Defines which value corresponds to the final position CLOSE

### Position unit

User level: Maintenance staff

Default value: %

**Description:**

Sets the dimension of the position unit for the display output. If the dimension has changed, depending parameters must be adjusted manually (e.g. scale values).

### Decimal Position

User level: Maintenance staff

Default value: 1

**Description:**

Sets the number of digits displayed after the comma in the main screen

## 7.4 Valve

---

### Closing direction

User level: Maintenance staff

Default value: Clockwise CW

**Description:**

Turning direction of the actuator, if the valve is closing, seen from the motor side of the actuator

### Switching off mode

User level: Maintenance staff

Default value: Final position limit sw.

**Description:**

Sets the switch-off conditions of the valve

### Max. runtime torque cut off

User level: Maintenance staff

Default value: 0

**Description:**

Within this time a waypoint must be followed by a torque signal. Otherwise a mechanical fault is assumed and the actuator stops giving an error indication.

### Tripping torque CLOSE

User level: Maintenance staff

**Description:**

The actuator switches off if the torque exceeds this value when closing

**Tripping torque OPEN**

User level: Maintenance staff

**Description:**

The actuator switches off if the torque exceeds this value when opening

**Torque warning CLOSE**

User level: Maintenance staff

**Description:**

The warning indication is activated if the torque exceeds this value when closing

**Torque warning OPEN**

User level: Maintenance staff

**Description:**

The warning indication is activated if the torque exceeds this value when opening

**Delay torque monitoring**

User level: Maintenance staff

Default value: 0

**Description:**

Sets the duration the actuator ignores torque trippings to filter out peaks in torque measurement.

**Limit to max. Torque**

User level: Maintenance staff

Default value: Enabled

**Description:**

If enabled the actuator monitors for the maximum adjustable torque during monitoring delay. If disabled the actuator operates at stall torque.

**Torque bypass final pos.**

User level: Maintenance staff

Default value: Disabled

**Description:**

Disables the torque detection during the time "Delay final positions" when trying to leave a final position.

If the torque still exceeds the "tripping torque" if the actuator leaves the end position or if the delay time is exceeded, a torque indication is generated and the actuator switches off.

**Delay time final pos.**

User level: Maintenance staff

Default value: 3000

**Description:**

Sets the duration the actuator can move with the breakdown torque of the motor - without a torque indication - to leave a final position

**Torque byp. interm. pos.**

User level: Maintenance staff

Default value: Disabled

**Description:**

Enables the breakdown torque of the motor when trying to leave an intermediate position. The bypass is not enabled if the actuator switched off due to a high torque.

**Delay time interm. pos.**

User level: Maintenance staff

Default value: 400

**Description:**

Sets the duration of the disabled torque detection if leaving an intermediate position

**Intermediate position 1 - 2**

User level: Maintenance staff

Default value: 25

**Description:**

Sets the value for the intermediate position 1 in the current unit

## 7. PARAMETERS

---

### **Tolerance pos. CLOSE**

User level: Maintenance staff

Default value: 0.5

**Description:**

Sets the range for the positioner to interpret a setpoint value as final position CLOSE. The actuator will move automatically until it reaches the final position if the setpoint value has a value between position CLOSE and this value. The final position is left if the setpoint value is higher than the final position plus the value of the parameter Xp.

Attention: for DPiM 30,59 and 119 the default value is set to 2%

### **Tolerance pos. OPEN**

User level: Maintenance staff

Default value: 0.5

**Description:**

Sets the range for the positioner to interpret a setpoint value as final position OPEN. The actuator will move automatically until it reaches the final position if the setpoint value has a value between position OPEN and this value. The final position is left if the setpoint value is higher than the final position minus the value of the parameter Xp.

Attention: for DPiM 30,59 and 119 the default value is set to 2%

### **Op-time survey CLOSE**

User level: Maintenance staff

Default value: 0

**Description:**

Sets the time which may not be exceeded when moving from OPEN to final position CLOSE at once. If the current running time is longer than this value, the indication "op-time survey" is activated. If this value is "0", the survey is disabled.

### **Op-time survey OPEN**

User level: Maintenance staff

Default value: 0

**Description:**

Sets the time which may not be exceeded when moving from CLOSE to final position OPEN at once.

If the current running time is longer than this value, the indication "op-time survey" is activated.

If this value is "0", the survey is disabled.

### **Delay startup CLOSE**

User level: Maintenance staff

Default value: 0

**Description:**

Sets a time delay for the activation of the command CLOSE for remote control, i.e. the command has to be activated longer than this value before the motor will be operated.

### **Delay startup OPEN**

User level: Maintenance staff

Default value: 0

**Description:**

Sets a time delay for the activation of the command OPEN for remote control, i.e. the command has to be activated longer than this value before the motor will be operated.

## 7.5 Actuator

---

### Thermal failure reset

User level: Maintenance staff

Default value: Automatic

**Description:**

A tripped motor protection requires the cooling down of the motor into a valid operating temperature range.

A reset of the failure indication and thus a new motor run is possible by

- automatic failure reset -> parameterisation to "Automatic"

- an explicit required manual confirmation -> parameterisation to „Manuell“

A failure confirmation can be done at the local control station as well as from a remote command or parameterisation in operation mode REMOTE.

In case of EX-proofed actuators, the parameterisation to "Automatic" is only allowed if the duty type is strictly observed.

### Thermal failure delay

User level: Maintenance staff

Default value: 1

**Description:**

Sets the time delay between detection of a motor overtemperature, and the indication and switch-off.

The temperature sensor is only powered by the main power of the actuator.

If the main power fails, the temperature detection is not powered, and therefore the motor

temperature is detected as too high. The motor overtemperature indication will be activated.

To suppress this indication due to short power failures, the delay time can be set.

### Actuator run monitor.

User level: Maintenance staff

Default value: Enabled

**Description:**

If enabled checks whether the position changes if the motor is energised.

This indication is reset with a new command or with a fault acknowledgement.

### Delay run monit.

User level: Maintenance staff

Default value: 1000

**Description:**

Sets the time of the parameter "Drive start up monitoring".

If the position has not changed significantly before the time elapses, the indication "Drive start up monit." is activated.

### Reversing delay

User level: Specialist

Default value: 400

**Description:**

Defines the dead time between reversal of rotation direction

### Power unit

User level: Specialist

Default value: Standard

**Description:**

Sets the type of the used power control unit. Choose the option Standard for standard contactor unit or standard solid state relay. Alternatively the option ATEX can be chosen for all pole disconnecting solid state relay.

## 7.6 DCS / PLC system

### 7.6.1 Emerg. shutdown (ESD)

---

#### **Emerg. shutdown (ESD)**

User level: Maintenance staff

Default value: 0% CLOSE

**Description:**

Sets the action of this function. If enabled the actuator moves to the specified final position.

The following indications can be activated to stop the movement or to be ignored.

#### **Motor overtemperature**

User level: Maintenance staff

Default value: Respect

**Description:**

If ignored the actuator moves to the specified final position even if the motor becomes too hot.

For explosion proofed actuators the setting has to be specified as "Respect".

Attention: The parameterization "Ignore" may result in damage and personal injury.

#### **Torque indication**

User level: Maintenance staff

Default value: Respect

**Description:**

This Parameter specifies the torque monitoring behaviour during an externally received emergency shutdown command.

Respect: Torque monitoring is operating normal. In case of a torque tripping in intermediate positions the actuator will stop with a fault indication.

Ignore: Torque monitoring is disabled during external emergency shutdown request. The actuator will drive into the specified direction without monitoring the torque.

This will result in an actuator movement with stall torque. If a torque final position cut off is specified in the respective direction the actuator will not stop in final position. In this case the value "Respect in final positions" should be specified.

Respect in final positions: Torque monitoring in intermediate positions is disabled during emergency shutdown.

The torque monitoring will be activated if the parameterized final position is reached .

#### **LOCAL mode**

User level: Maintenance staff

Default value: Respect

**Description:**

If ignored the actuator moves even if the mode is Local.

Attention: The parameterization "Ignore" may result in damage and personal injury.

**OFF mode**

User level: Maintenance staff

Default value: Respect

**Description:**

If ignored the actuator moves even if the mode is OFF.

Attention: The parameterization "Ignore" may result in damage and personal injury.

**7.6.2 Fail safe****Reaction**

User level: Maintenance staff

Default value: Disabled

**Description:**

Sets the action of the actuator if the set-point value does not lie in the range 3.0...22 mA, or the fieldbus communication fails for a longer duration than specified with the parameter "Breakdown delay".

**Position modulating act.**

User level: Maintenance staff

Default value: 0

**Description:**

Sets the fail safe position for an actuator with integrated positioner

**Position on-off actuator**

User level: Maintenance staff

Default value: 0% CLOSE

**Description:**

Sets the fail safe position for an on-off or inching actuator

**Breakdown delay**

User level: Maintenance staff

Default value: 1

**Description:**

Sets the time of the delay between failure and activation of the fail safe action.

**7.6.3 Collective failure 1 - 2****Failure of internal 24V**

User level: Maintenance staff

Default value: Enabled

**Description:**

Indicates whether the internal power of 24 V DC - generated from mains power L1, L2 - is OK or failed. Enabling this indication makes only sense if the actuator is additionally powered by 24 V DC (either by external source or by battery backup). Otherwise - in case of a failure of the main power and thus a failure of the internal power, too - the electronic unit is deenergised, and therefore without function.

**Failure of external 24V**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates whether the external power of 24 V DC is OK or failed.

**Phase failure**

User level: Maintenance staff

Default value: Enabled

**Description:**

Indicates whether a phase of the main power is missing. The indication is reset with the next movement or with a fault acknowledgement. If one of the two phases L1 and L2, which supply the electronic fail, the electronic will be without function. Only if the electronic is powered with additional 24 V DC, the failure of those two phases can be indicated.

## 7. PARAMETERS

---

### **Actuator not starting**

User level: Maintenance staff

Default value: Enabled

**Description:**

If the time "Delay run monit." elapses while the motor is energised, and the position did not change significantly during this period, this indication is activated. This indication can be reset by a new movement or with a fault acknowledgement.

### **Torque failure**

User level: Maintenance staff

Default value: Enabled

**Description:**

Indication is activated if the torque exceeds one of the values for the tripping torque

### **Torque CLOSE**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates that the closing torque exceeded the "tripping torque" when closing the valve. The indication can be reset by moving the actuator into the other direction or with a fault acknowledgement.

### **Torque OPEN**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates that the opening torque exceeded the "tripping torque" when opening the valve.

The indication can be reset by moving the actuator into the other direction.

### **Torque warning**

User level: Maintenance staff

Default value: Disabled

**Description:**

Is activated if the torque exceeds one of the values for the torque warning

### **Torque warning CLOSE**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates that the closing torque exceeds the warning value when closing the valve. The indication can be reset by moving the actuator into the other direction.

### **Torque warning OPEN**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates that the opening torque exceeds the warning value when opening the valve. The indication can be reset by moving the actuator into the other direction.

### **Motor overtemperature**

User level: Maintenance staff

Default value: Enabled

**Description:**

Indication is activated if the motor temperature exceeds the permissible value.

### **Discrepancy power unit**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates an error with the internal discrepancy analysis of the power module.

### **OFF mode**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates that the actuator cannot move

**LOCAL mode**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates that the actuator can be controlled by using the display unit.

**Emerg. shutdown tripped**

User level: Maintenance staff

Default value: Disabled

**Description:**

Is activate as long as the actuator executes an emergency shutdown

**Fail safe**

User level: Maintenance staff

Default value: Enabled

**Description:**

Is active as long as the actuator is in the mode fail safe.

**Hardware failure**

User level: Maintenance staff

Default value: Enabled

**Description:**

Indicates that during self test the electronic detected defective hardware components

**Systemtest fault**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates that during self test the electronic detected a system test fault

**Combisensor failure**

User level: Maintenance staff

Default value: Enabled

**Description:**

Indicates that the electronic detected a malfunction of the combined sensor during self test. This indication lasts as long as the error. While this error is active, the actuator cannot be moved! The control unit tries to re-initialise the combined sensor to clear the error.

**Int. positioner disabled**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates if the positioner of an actuator of type DiMxx5 is not enabled (command AUTOMATIC not active).

**Maintenance required**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates if a limit of the operation data is exceeded.

**Mode not REMOTE**

User level: Maintenance staff

Default value: Disabled

**Description:**

Is active if the actuator is not in mode REMOTE

**Configuration invalid**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates, that at least one of the tripping torques exceeds the maximum permissible torque values of either the additional component or the valve.

## 7. PARAMETERS

---

### **Electronic overtemp.**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates, that the electronic temperature is exceeding the permissible value

### **Direction monitoring**

User level: Maintenance staff

Default value: Enabled

**Description:**

Indicates, that the actuator is turning the wrong way.

This indication can be reset by a new movement or with a fault acknowledgement.

### **Handwheel operation**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates, that the position of the actuator is changing without giving a command to the motor.

The indication is active as long as the position changes.

### **Op-time survey**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates, if the current running time exceeds one of the two values of "Op-time survey CLOSE" or "Op-time survey OPEN"

### **Battery backup malf.**

User level: Maintenance staff

Default value: Disabled

**Description:**

Indicates an error with the internal accumulator. If this indication is active, the control unit cannot be supplied by the battery backup in case of mains power loss.

## 7.6.4 Control

---

### **Control mode**

User level: Maintenance staff

Default value: Inching operation

**Description:**

Sets the function of the REMOTE command inputs. In "Inching operation" the command is active as long as the signal is active. In "Maintain mode" the command is activated with an edge triggered command and deactivated in case of final position switch off, a command in reverse direction or stop command, or actuator switch off due to failure.

### **Maintain in final pos.**

User level: Maintenance staff

Default value: Enabled

**Description:**

Defines whether the actuator shall move automatically into the final position even after removing the command, if in the end position. Enable only if the valve has at least one final position with switch-off by torque!

## 7.6.5 Indications

---

### **Final position indication**

User level: Maintenance staff

Default value: Position

**Description:**

Sets the indication of the final positions. If set to "Position" the indication is activated if the limit positions are reached. If set to "Act. cut off mode" the indication is only activated if the actuator reaches the final positions.

**Torque indication**

User level: Maintenance staff

Default value: Ind. in final positions

**Description:**

Sets whether a torque exceeding the tripping torque shall or shall not be indicated if the actuator is in an end position.

**Torque fault**

User level: Maintenance staff

Default value: No ind. in final positions

**Description:**

Sets whether a torque exceeding the tripping torque shall or shall not be indicated as fault if the actuator is in an end position.

---

**7.6.6 Interface****Position output**

User level: Maintenance staff

Default value: Over-/underflow

**Description:**

Defines how the position is output:

- With "Over-/underflow" the position is not limited to values between CLOSE and OPEN (see data logging -> high scale value, low scale value)
- With "Limited" the displayed position is limited to the range between CLOSE and OPEN

**7.6.6.1 Profibus****7.6.6.2 Modbus**

---

**Primary slave address**

User level: Maintenance staff

Default value: 247

**Description:**

Sets the primary address for the Modbus system in the range between 1 and 247.

Attention: Changes will only take effect after actuator restart.

**Sec. slave address**

User level: Maintenance staff

Default value: 247

**Description:**

Sets the secondary address of the Modbus system in the range between 1 and 247.

Attention: Changes will only take effect after actuator restart.

**Baudrate**

User level: Maintenance staff

Default value: 38400

**Description:**

Defines the transmission speed.

Attention: Changes will only take effect after actuator restart.

**Parity**

User level: Maintenance staff

Default value: None

**Description:**

Defines the parity.

Attention: Changes will only take effect after actuator restart.

## 7. PARAMETERS

---

### Timeout

User level: Maintenance staff

Default value: 50

**Description:**

Sets the timeout in units of 100ms.

### Redundancy reply

User level: Maintenance staff

Default value: Both channels

**Description:**

Defines, whether a telegram to the master is send on both channels, or only on the channel where the telegram from the master has been received.

Attention: Changes will only take effect after actuator restart.

### 7.6.6.3 DeviceNet

---

#### Primary slave address

User level: Maintenance staff

Default value: 1

**Description:**

Sets the primary address of the DeviceNet system in the range between 0 and 63.

#### Sec. slave address

User level: Maintenance staff

Default value: 1

**Description:**

Sets the secondary address of the DeviceNet system in the range between 0 and 63.

#### Baudrate

User level: Maintenance staff

Default value: 125k

**Description:**

Defines the transmission speed.

### 7.6.6.4 Process inputs-Bus

---

#### Process input 1 - 4

User level: Maintenance staff

Default value: Disabled

**Description:**

Defines, whether this input is used as an input for an external component, or as an additional command input. If disabled, the signals of the external component are transmitted via the fieldbus system to the master station. As an additional command input, the possible functions can be assigned.

#### Logic Process input 1 - 4

User level: Maintenance staff

Default value: high-active

**Description:**

Sets whether the process input, if configured as command input, is high- (active with 24 V) or low-active (active with 0 V).

### 7.6.6.5 Relay interface

---

#### Fail safe reaction

User level: Maintenance staff

Default value: Ignore Automatic

**Description:**

Defines whether for actuators with internal positioner the fail safe action is only performed if the automatic command is active or in every case.

### 7.6.6.5.1 Outputs

---

#### **Output O1 - 12**

User level: Maintenance staff

Default value: Final position CLOSE

**Description:**

Defines the functions of the outputs.

The functions can be allocated to the outputs in any way.

#### **Logic Output O1 - 12**

User level: Maintenance staff

Default value: NO contact

**Description:**

The physical implementation of the indication outputs are normally open contacts (NO).

If configured to normally closed contacts (NC), the relays are powered if the indication

is not active, and deenergised if the indication is active.

If power fails, these relays are released, and output thus an active signal.

### 7.6.6.5.2 Analogue outputs

---

#### **Analogue output 1 - 2**

User level: Maintenance staff

Default value: Position

**Description:**

Defines which kind of information should be output as a 4...20

mA signal using analogue output 1.

The calibration of the analogue signals - only possible for position output - can be done using the parameters of the Learn mode.

The possible parameters are situated in the submenu "Analogue signal>output", and include "Value 100%" and "Value 0%".

Those parameters have the same effect on output 1 and 2.

The range for the analogue signals is:

-Position: CLOSE...OPEN

-torque: Depending on the configuration of the parameter

"Data logging>Torque sign" either - 100%...+100%, or 0...100%

Electronic temperature: -25°C...+100°C

### 7.6.6.5.3 Command inputs

---

#### **Delay**

User level: Maintenance staff

Default value: 0

**Description:**

Specifies the minimum impulse time for the digital command inputs.

A command must be at least valid for the duration of the parameterized delay in order to take effect.

#### **Command input 1 - 6**

User level: Maintenance staff

Default value: Stop

**Description:**

Defines the functions of the command inputs.

The functions can be allocated to the command inputs in any way.

## 7. PARAMETERS

---

### Logic Command inp.1 - 6

User level: Maintenance staff

Default value: high-active

**Description:**

Defines if the command is active with 24 V DC (high-active) or with 0 V (low-active).

### Fail safe reaction

User level: Maintenance staff

Default value: Ignore Automatic

**Description:**

Defines whether for actuators with internal positioner the fail safe action is only performed if the automatic command is active or in every case.

### Position output

User level: Maintenance staff

Default value: Over-/underflow

**Description:**

Defines how the position is output:

- With "Over-/underflow" the position is not limited to values between CLOSE and OPEN (see data logging -> high scale value, low scale value)
- With "Limited" the displayed position is limited to the range between CLOSE and OPEN

### Enhanced controller

User level: Maintenance staff

Default value: Disabled

**Description:**

Settings for the enhanced controller (like the inner and outer deadband).

### Adaptive behaviour

Default value: Disabled

**Description:**

Controlling parameters are calculated automatically with regard to the overrun of the actuator.

### Deadband OPEN

User level: Maintenance staff

Default value: 0.5

**Description:**

modulating tolerance in direction OPEN

### Deadband CLOSE

User level: Maintenance staff

Default value: 0.5

**Description:**

modulating tolerance in direction CLOSE

### Outer deadband

User level: Maintenance staff

Default value: 0.5

**Description:**

Delay time before the actuator reacts to another deviation from the setpoint, if the actuator had stopped already.

### Dead time

User level: Maintenance staff

Default value: 0

**Description:**

Delay time of a reaction to a deviation from the set point value.

## 7.7 Process

---

### Accuracy Xp

User level: Maintenance staff

Default value: 2.5

**Description:**

Sets the dead band around the setpoint value of the positioner.

The dead band is distributed around the setpoint value by the value of Xp to the positive and to the negative direction.

**Step. mode pulse source**

User level: Maintenance staff

Default value: Internal

**Description:**

Sets the source which controls whether the stepping mode is active.

If set to "Internal", the stepping mode is active from position CLOSE

to "Start pulse internal". If set to "External", the stepping mode is

active as long as the command is active and the actuator turns

into a direction the stepping mode has been enabled.

**Stepping mode select**

User level: Maintenance staff

Default value: linear

**Description:**

Sets the cyclic pulse time Ton to a fixed value (Linear),

or reduces the time Ton from the specified value to the minimum

value of 0.5 seconds during movement (Decreasing).

With decreasing stepping mode, the minimum Ton is reached in

final position CLOSE - regardless of the direction.

**Start pulse internal**

User level: Maintenance staff

Default value: 25

**Description:**

Defines the second limit of the stepping mode.

The first limit is always position CLOSE.

**Stepping mode opening**

User level: Maintenance staff

Default value: Disabled

**Description:**

Enables the stepping mode if opening the valve.

**Stepping mode closing**

User level: Maintenance staff

Default value: Disabled

**Description:**

Enables the stepping mode if closing the valve.

**Stepping mode T on**

User level: Maintenance staff

Default value: 500

**Description:**

Sets the duration the motor is energised during cyclic operation.

**Stepping mode T off**

User level: Maintenance staff

Default value: 700

**Description:**

Sets the duration the motor is deenergised during cyclic operation.

**Load factory settings**

User level: Maintenance staff

Default value: No

**Description:**

The factory setting will be loaded

**Store factory settings**

User level: Specialist

Default value: No

**Description:**

Stores the settings as factory setting.

## 8 Failures

### [1] - Torque OPEN

Tripping torque OPEN has been exceeded.

**Solution:**

Is reset by movement into other direction or by acknowledgement.

### [2] - Torque CLOSE

Tripping torque OPEN has been exceeded.

**Solution:**

Is reset by movement into other direction or by acknowledgement.

### [3] - Actuator start monitor.

Valve position has not changed in spite of powered motor.

**Solution:**

Check mechanical parts and components of power circuit.

### [4] - Direction monitoring

Actuator is running into wrong direction.

**Solution:**

Check setting of "phase sequence".

### [5] - Thermal overload

Thermal overload.

**Solution:**

Cool down motor.

### [6] - Electronic overtemp.

Electronic unit too hot.

**Solution:**

Cool down electronic unit.

### [7] - dummy

Future use

### [8] - Fail safe

Actuator is in state fail-safe.

**Solution:**

Is reset when state fail-safe is left.

### [9] - Hardware failure

Electronic unit has detected a hardware error during selfcheck.

**Solution:**

Replace broken parts.

### [10] - Encoder failure

Electronic unit has detected an error of the combined sensor during self-check.

**Solution:**

Is reset if error has been cleared. If error is still present exchange sensor.

**[11] - Encoder setup failure**

Limit positions are not set correctly.

**Solution:**

Erasing and new setting of limit positions.

**[12] - Torq. inp. gear exceed.**

Additional information to indication "Configuration invalid".

**Solution:**

Set tripping torque values smaller than the permissible input torque of the gear.

**[13] - Valve torque OPEN**

Additional information to indication "Configuration invalid".

**Solution:**

Set tripping torque values in open direction smaller than the permissible input torque of the gear.

**[14] - Valve torque CLOSE**

Additional information to indication "Configuration invalid".

**Solution:**

Set tripping torque values in close direction smaller than the permissible input torque of the gear.

**[15] - Systemtest fault**

Electronic unit has detected an error during self-check.

**Solution:**

Depending on detected error.

**[16] - 24V internal failure**

Failure of the internal 24V DC powered by the mains voltage system.

**Solution:**

Is automatically reset if voltage returns.

**[17] - 24V external failure**

Failure of the additional, external 24V DC.

**Solution:**

Is automatically reset if voltage returns.

**[18] - Phase 1 failure**

Failure of phase 1.

**Solution:**

Is reset with a new movement or with a fault acknowledgement.

**[19] - Phase 2 failure**

Failure of phase 2.

**Solution:**

Is reset with a new movement or with a fault acknowledgement.

**[20] - Phase 3 failure**

Failure of phase 3.

**Solution:**

Is reset with a new movement or with a fault acknowledgement.

**[21] - Phase correction failure**

Indicates that the automatic phase detection is not working properly.

**Solution:**

Set "Phase correction" manually.

**[22] - Battery backup malf.**

Battery backup is not able to power the electronic unit.

**Solution:**

Load if Accumulator empty, else exchange it if battery backup is defective.

**[23] - dummy**

Future use

**[24] - Emerg. shutdown (ESD)**

Actuator is in state emergency shutdown.

**Solution:**

Is reset when emergency shutdown is left.

**[25] - Discrepancy error**

Discrepancy between the active command and the state of the power unit.

**Solution:**

Acknowledgement of the according indication after fixed error.

**[26] - Wrong power unit**

Configured power unit does not match with the existing one (for example after a modification).

**Solution:**

If the configuration is wrong it has to be corrected otherwise if the power unit is wrong it has to be replaced by the correct one.

**[27] - dummy**

The emergency stop command is active.

**Solution:**

The command can be deactivated after clearing the emergency situation.

**[28] - OFF mode**

Actuator in mode OFF.

**Solution:**

Change mode of operation.

**[29] - LOCAL mode**

Actuator in mode LOCAL.

**Solution:**

Change mode of operation.

**[30] - Mode not REMOTE**

Actuator not in mode REMOTE.

**Solution:**

Change mode of operation to REMOTE

**[31] - dummy**

Future use

**[32] - dummy**

Future use

**[37] - dummy**

Future use

**[33] - Configuration invalid**

Tripping torque values exceed permissible values of additional components. An other possibility is a discrepancy between configured Profibus-profile and permitted Profibus-profile by device key.

**Solution:**

Adjust the tripping torque or the Profibus-profile according to the given limits.

**[38] - dummy**

Future use

**[39] - dummy**

Future use

**[34] - NV-Memory failure**

Electronic unit has detected an error of the non-volatile memory during self-check.

**Solution:**

Exchange electronic unit.

**[40] - Limit valve strokes**

The set number of motor operations has been exceeded.

**Solution:**

Clear current value or increase limit.

**[35] - HW interface failure**

Electronic unit has detected an error of the interface board during self-check.

**Solution:**

Exchange interface board.

**[41] - Accum. operation cycles**

The permitted number of operations for the valve is exceeded.

**Solution:**

Will be acknowledged when the actual value of operations for the valve gets lower than the limit.

**[36] - Device key invalid**

The device key is not valid.

**Solution:**

Contact manufacturer for valid device key and enter it.

**[42] - Current op. cycles/h**

The set number of operation cycles per hour has been exceeded.

**Solution:**

Clear current value or increase limit.

**[43] - Op-time survey OPEN**

The current motor operation time has exceeded the limit of direction OPEN.

**Solution:**

Is reset if value is smaller than limit.

**[44] - Op-time survey CLOSE**

The current motor operation time has exceeded the limit of direction CLOSE.

**Solution:**

Is reset if value is smaller than limit.

**[45] - Gasket change recomm.**

The value for thermal age exceeds the given limit.

**Solution:**

Change all gaskets of the actuator to ensure its protection class and reset value "Thermal ageing" in "data oper. acquisition" afterwards.

**[46] - Gear overhaul recomm.**

The value for mechanical age exceeds the given limit.

**Solution:**

Check internal gear of the actuator and exchange exhausted parts. Reset value "Mechanical ageing" in "data oper. acquisition" afterwards

**[47] - dummy**

Future use

**[48] - Torque warning OPEN**

The current torque value has exceeded the value "Torque warning OPEN".

**Solution:**

Is reset by movement into other direction.

**[49] - Torque warning CLOSE**

The current torque value has exceeded the value "Torque warning CLOSE".

**Solution:**

Is reset by movement into other direction.

**[50] - Handwheel operation**

The position of the valve changes although the motor is not powered.

**Solution:**

Is cleared automatically if position does not change.

**[51] - Maintenance required**

A limit of the operation data has been exceeded.

**Solution:**

Clear current value or increase limit.

**[52] - Int. positioner disabled**

An actuator with internal positioner has the command "AUTOMATIC" disabled.

**Solution:**

Is cleared if command "AUTOMATIC" is given.

**[53] - dummy**

Future use

**[54] - dummy**

Future use

**[55] - dummy**

Future use

## 9 Collective failures

This chapter contains a description of the differences between the two collective failures.

### 9.1 Activation of the indications

The actual firmware allows the configuration of COLLECTIVE FAILURE 1 and COLLECTIVE FAILURE 2. Both of them contain a list of indications that can be activated. Each parameter set to **activated** triggers the collective failure under which he is activated:ls **AKTIVIERT** parametriert worden ist:

- Failure of internal 24V
- Failure of external 24V
- Phase failure
- Actuator not starting
- Torque failure
- Torque CLOSE
- Torque OPEN
- Torque warning
- Torque warning CLOSE
- Torque warning OPEN
- Motor overtemperature
- Discrepancy power unit
- OFF mode
- LOCAL mode
- Emerg. shutdown tripped
- Fail safe
- Hardware failure
- Systemtest fault
- Combisensor failure
- Int. positioner disabled
- Maintenance required
- Mode not REMOTE
- Configuration invalid
- Electronic overtemp.
- Direction monitoring
- Handwheel operation
- Op-time survey
- Battery backup malf.

If there is an indication active that is set under `COLLECTIVE FAILURE 1` the LED indicating a failure will be on and there appears a bell on the display( refer to figure 9.1).




Figure 9.1: Bell

Every other indication out of the list above or the list of failures will cause a triangular warning sign to appear on the display (refer to figure 9.2).



Figure 9.2: Triangular warning sign

# 10 Digital In- and outputs

This chapter contains information about the possibilities of configuration for the process- and command inputs and the Outputs

## 10.1 Configuration of the outputs

The actual firmware allows a free configuration of the outputs. Therefor one of the following indications has to be selected for the according output.

The selectable indications are:

- Final position
- Final position CLOSE
- Final position OPEN
- Pos. b. CLOSE and Int.1
- Pos. b. Int.2 and OPEN
- Act. running-permanent
- Act. running-flashing
- Act. closing-permanent
- Act. closing-flashing
- Act. opening-permanent
- Act. opening-flashing
- Actuator not starting
- Torque tripping
- Torque tripping CLOSE
- Torque tripping OPEN
- Torque warning
- Torque warning CLOSE
- Torque warning OPEN
- Collective failure 1
- Collective failure 2
- Motor overtemperature
- Remote control
- OFF
- Local control
- Emerg. shutdown tripped
- Fail safe
- Hardware failure
- Combisensor failure
- Int. positioner disabled
- Maintenance required
- Mode not REMOTE
- Handwheel operation
- Systemtest fault

After an indication has been assigned to an output the type of the output (**NC contact** oder **NO contact**) has to be selected. Contacts that are parametrized to behave like NC contacts have to switched to this behavior by the software, because the hardware has always NO contacts. That is the reason why the control unit must be energized for the NC contacts to work properly.

## 10.2 Configuration of the process- and command inputs

The actual firmware allows a free configuration of the inputs. Therefore one of the following indications has to be selected for the according input. The amount of inputs may vary depending on the hardware configuration of the actuator.

The selectable commands are

- Stop
- CLOSE
- OPEN
- Automatic
- Emerg. shutdown (ESD)
- Stepping mode active
- Enable LOCAL
- Enable REMOTE
- Enable CLOSE
- Enable OPEN
- Fault acknowledge
- Force LOCAL
- Force LOCAL STOP
- Force LOCAL CLOSE
- Force LOCAL OPEN

After a command has been assigned to an input the type of the input (**HIGH-ACTIVE** or **LOW-ACTIVE**) has to be selected.

# 11 Anotations for explosion proof actuators

In this chapter the dependencies between some of the parameters and the protection against explosion will be described. The according parameters and their correct configuration will be shown.

## 11.1 The affected parameters

- Thermal failure reset
- Thermal overload
- Power unit



### **DANGER**

**If these parameters are changed the actuator may not be explosion proof anymore.**

- The Information in this chapter has to be regarded.

## 11.2 Keeping the actuator explosion proof

### 11.2.1 Thermal failure reset.

This parameter regulates the behavior of the actuator after the motor got overheated. It must be set to **MANUELL** to prevent to motor from running automatically after cooling down. This is the default setting after production and if not set correctly the actuator will not longer be explosion proof. The error that is indicated when the motor gets too hot must be reset manually before the actuator can be operated again.

### 11.2.2 Thermal overload

Monitoring the over temperature of the motor must be set to **RESPECT** in the parameter **emergency shut down (ESD)**. Otherwise the motor will get too hot and the actuator is not longer explosion proof.

### 11.2.3 The power unit

This parameter adjusts the power unit to the control unit. If the actuator is not equipped with an Ex solid state relay (SSR) (solid state relay that disconnects all pins) the parameter must be set to **contactors or SSR**. Use of normal SSR (one pin is permanently conducted) is only allowed in combination with a circuit breaker that disconnects all pins (as described in the actuators operation manual). For use with an Ex SSR the parameter has to be set to **Ex solid state relay** to keep the actuator explosion proof.



# **DREHMO**

## **VALVE ACTUATORS**

**A member of the AUMA Group**



**DREHMO GmbH**  
**Zum Eichstruck 10**  
**57482 Wenden/Germany**  
**Phone: +49 2762 9850-0**  
**Phone service: +49 2762 9850-204**

**Internet: [www.drehmo.com](http://www.drehmo.com)**  
**E-mail: [drehmo@drehmo.com](mailto:drehmo@drehmo.com)**